



Dragon Staff Kit Assembly Instructions

Congratulations on your recent purchase of our newly designed Home of Poi dragon staff kit!!

This dragon staff kit has been designed to fit over poles ranging from 19mm to 22mm in diameter only.

When attaching the kit hubs onto the staff pole ensure all the spokes are out of the hub, this will make it easier to screw the hub into place.

As a guide if you are putting the kit on a staff with no wicks, the flat edge of the hub should sit just back from the end of the pole (about 5 mm or more) this will help to protect the hubs when dropped. If a staff is being used that already has wicks then we recommend the hubs are placed 1-2 inches a way from the staff wick approximately.

Unscrew your hub halves completely using the provided Allen or hex key so they are apart and not attached in any way.

Then place the two halves on the pole evenly facing the same way up. Place the two bolts back into the hole just enough so they grip the corresponding hub half. Then making sure they are tightened evenly together, as you do not want one side pulling more than the other, tighten them slowly until the hubs are securely clamped to the pole evenly.

Very Important not to overtighten!! As this may cause damage to the thread. Then insert the spokes using the push button so they align into the corresponding holes in the Hubs. To take the spokes out simply push the button in for the corresponding spoke and twist/pull out.

For more information feel free to contact our support team at support@homeofpoi.com or visit our website www.homeofpoi.com

Happy Dragon Spinning!!